




# SMART CABLE REPLACEMENT TUTORIAL


SINGLE BASE

# HARDWARE OVERVIEW



## STEP 1 A LOCATE

Your bed should have a Sleeptracker-AI® Smart Cable mounted underneath the base. Locate the Smart Cable on your base.




Your base's configuration may be different, depending on the size and model, however, your base should only have one Smart Cable mounted underneath the base.

# STEP B || REMOVE


Remove the USB cable and the DIN plug (round 5-pin plug) going into the Smart Cable. Next, unplug the Smart Cable’s DIN output from the Control Box’s splitter input, and then remove the Smart Cable body from the mount.

The Smart Cable can be removed from the mount by pulling the device out & away from the base/mount.

You **do not** need to remove the screws holding in the mount. You can simply grab the cable coming out of the Smart Cable body, and then pull the Smart Cable body out of the mount.



# STEP C || INSTALL





Insert your new Smart Cable into the mount, and then ① firmly push the Smart Cable’s DIN output into the splitter’s DIN input. ② Insert the Battery Backup Boxes’ DIN output into the Smart Cable, and ③ plug the USB cable in.

**NOTE** A loose DIN cable connection can cause features on the base to not work properly, so ensure all DIN cable connections you encounter are connected firmly.

STEP


D || REVERIFY

In the Tempur® Sleeptracker-AI® app, select...




NOTE

If the correct bed type is *not* shown in the image and/or the Type is *not* set to “Power base bed”, please factory-reset the Processor and then go to **Menu** > **Pair with a Smart Bed**, to properly set it up again.



Ensure your sensors are correctly placed on your base, as directed. Afterward, scroll to the bottom of the screen to select **Next** & proceed.



VISIT

SLEEPTRACKER.COM/SUPPORT/  
TEMPUR

FOR ADDITIONAL HELP

&

INFORMATION